

SAFARI RANGE

INSTRUCTION OF USE

To adjust back height hold back with two hands while seated and raise to desired height

To lower the back height raise back all the way to the top and release slowly

RIGHT BACK LEVER


To adjust back angle

RIGHT FRONT LEVER

To adjust seat height

700MM BLACK NYLON 6 STAR BASE WITH CASTORS

Use soft tyred castors for tiles
Use hard tyred castors for carpet



INDOOR USE ONLY

**OPTIONAL
ADJUSTABLE ARMS**

LEFT LEVER

To adjust seat angle

X Do not use as a step ladder

DIMENSIONS: (mm)

LOW BACK LOW BACK TO FLOOR

W: 440 Lowest: 930
H: 400 Highest: 1140

HIGH BACK HIGH BACK TO FLOOR

W: 450 Lowest: 990
H: 510 Highest: 1185

SEAT

W: 530
D: 480

SEAT TO FLOOR

Lowest: 530
Highest: 670

ARM TO FLOOR

Lowest: 670
Highest: 880

Fabric: Chelsea bark



SA350H



SA350



SA200

Optional:



Drafting kit



Adjustable arm

Features:

Adjustable seat height
Adjustable back height (ratchet)
Adjustable seat angle
(with 3 lever mechanism only)

Adjustable back angle
Optional 2 or 3 lever mechanism
Moulded seat and back foam
Firm kidney and lumbar support

Big boy seat
700mm black nylon 6 star base
Available in local fabrics
Suitable for indoor use only

